

IMPORTANT SAFETY INSTRUCTIONS



- (a) Read and follow all safety instructions.
- (b) Do not cover this product as the covering may cause the flexible light to overheat and melt or ignite.
- (c) Do not operate with the flexible light tightly coiled.
- (d) Do not puncture, cut, shorten, or splice the flexible lighting.
- (e) Do not route the cord or flexible lighting cable through walls, doors, windows or any like part of the building structure.
- (f) Do not use if there is any damage to the light or cord insulation. Inspect periodically.
- (g) Do not submerge flexible light in liquids, or use the product in the vicinity of standing water or other liquids.
- (h) Secure this flexible light cable using only the hangers or clips provided. Do not secure this product or its cord with staples, nails, or like means that may damage the insulation.
- (i) Do not subject flexible lighting to continuous flexing.

WARNING: When using OUTDOOR use portable lighting products, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following: (READ ALL INSTRUCTIONS)

(A) Ground Fault Circuit Interrupter (GFCI) protection should be provided on the circuits or outlet to be used for the outdoor use flexible lighting product. Receptacles are available having built-in GFCI protection for this measure of safety.

(B) Use only outdoor extension cords, such as type SW, SOW, STW, STOW, SJW, SJOW, SJTW, or SJTOW. This designation is marked on the wire of the extension cord.

HOW TO USE

With mounting clip

- Use a nail to fix the mounting clip.
- Press the flexilight into the mounting clip.

With channel

- a) on glass surface:
 - Glue the channel on the glass surface.
 - Press the flexilight in the channel

With channel

- a) on wooden material
 - Fix the channel with nails.
 - Press the flexilight in the channel

LIMITED WARRENTY

Wide Loyal Lighting Limited (hereinafter called "Wide Loyal") hereby warrants to the first consumer purchaser only, that this Wide Loyal product in free, under normal use and service, from any defects in material and workmanship. If any defects should be found in this product within the applicable warranty period, Wide Loyal shall, at its sole option, repair or replace this products.

Wide Loyal disclaims any and all liability for direct or indirect damages or losses or for any incidental, special or consequential damages or loss of profits resulting from a defect in material or workmanship relating to the product, including damages for the loss of time or use of this Wide Loyal products. The purchaser will be responsible for any removal, reinstallation, transportation and insurance costs incurred.

All warranty claims should be addressed to Service Dept., **Wide Loyal Development Ltd, #102-3820 Jacombs Road, Richmond B.C. V6V 1Y6 Canada**, together with the original cope of the sales receipts.

WARRANTY PERIODS:

Flexilight	1 year
Flexilight Accessories & Controllers	3 months
Flexi-Star	3 months
Pearl Light & Shell Light	3 months
Flexi-Art	3 months
Gift & Premium	3 months